



REFURBISHING/REPAIR

HOT OIL PUMPS, 10" & 12" DISK DOUBLE MECHANICAL SEAL

Standard Procedure
(Shop level repair):

- Delivery unit to shop
- Disassemble the unit
- Check all parts, visually and dimensionally
- Machine bushing to tolerances
- Rework the fasteners
- Replace bearings
- Replace mechanical seal
- Replace bushing
- Replace gasket seals
- Reassemble and test at no load

Site assembly:

- Assemble the pump to motor
- Reroute seal lubrication hoses
- Connect water cooling tower and piping
- Connect electrical controls to motor
- Test unit under normal operating conditions
- Check for leaks and overloads
- Rework if needed



DANTCO MIXERS CORPORATION
9 OAK STREET
PATERSON, NJ 07501-3013
973-278-8776, FAX 973-278-1538
EMAIL sales@dantco.com, WEB <http://www.dantco.com>



REFURBISHING/REPAIR

HOT OIL PUMPS, 10" & 12" DISK DOUBLE MECHANICAL SEAL

Standard Procedure
(Shop level repair):

- Delivery unit to shop
- Disassemble the unit
- Check all parts, visually and dimensionally
- Machine bushing to tolerances
- Rework the fasteners
- Replace bearings
- Replace mechanical seal
- Replace bushing
- Replace gasket seals
- Reassemble and test at no load



DANTCO MIXERS CORPORATION
9 OAK STREET
PATERSON, NJ 07501-3013
973-278-8776, FAX 973-278-1538
EMAIL sales@dantco.com, WEB <http://www.dantco.com>